


Follow the instructions included with your shelving packs and apply the following shelf spacings for the kit you have purchased. The spacings relate to 'keyholes' – leave the quantity of keyholes between shelves.

Clear Keyholes

Note: all packs of steelwork contain 4 shelves, these kits use 5 per bay so will have an extra level



x8

x11

x11

x11

x1

Remember to include the 2 keyholes where the joiner is