


Follow the instructions included with your shelving packs and apply the following shelf spacings for the kit you have purchased. The spacings relate to 'keyholes' – leave the quantity of keyholes between shelves.

## Clear Keyholes

Note: all standard packs of steelwork contain 4 shelves, these kits use 6 per bay so will have 2 extra levels



x7

x8

x8

x8

x8

x1

Remember to include the 2 keyholes where the joiner is